

OMNICOMM

Omnicom OBdII Terminal

User Manual

24.05.2019

Contents

4	General information
4	Installation
4	SIM Card Inserting
5	Connector Pin Assignment
5	Terminal Connection
6	Setting Overview
7	Default Settings
10	Primary Activation
11	Omnicom Configurator
12	Remote Configuration Server (RCS)
12	SMS Commands
12	Commands Format
14	System Commands
22	Settings
32	Parameter Setting Request
36	Current Values Request
39	Event Notifications
39	Operation Parameters Setting
39	GPRS Connection
40	OBD Bus
41	OBD parameters tab to SAE J1979, SAE J1939
42	Connection to Communication Servers
43	Data Collection

44	Data Transmission to a Communication Server
46	Selection of Ignition Source
46	Selection of Speed Source
47	Engine RPM
47	Fuel Level Sensors
47	Internal Battery
48	Driving Safety Control

51 **Service Functions**

52	Terminal Reboot
52	Setting Password on Configuration Changing
53	Data Collection and Transmission Blocking
54	Remote Configuration Server Operation Setting
54	Terminal SIM Card Number Identification

55 **Installation of a Protective Sticker**

55 **Sealing**

55 **Specifications**

Omnicom OBDII Terminal

General information

Omnicom OBDII terminal is an on-board equipment designed to gather information on the vehicle parameters and transmit data to Omnicomm Online or a third-party fleet monitoring system.

Main functions:

- determining a vehicle's location, speed, and movement direction
- determining the current status of the vehicle through the OBDII connector
- driver sound alert
- VH impact logging
- driving safety control
- data storage in non-volatile memory
- transferring data to Omnicomm Online or to third-party software

Installation

SIM Card Inserting


Before SIM card inserting, disable PIN request at activation. To this end insert the card in any cell phone and disable PIN request, according to the cell phone operating instruction.

If using commands in SMS messages, enable the Short Message Service.

Insert the SIM card into the connector, contacts down, until it clicks.

General information

Connector Pin Assignment



No. of pin	Designation
4	Vehicle body grounding
5	Signal grounding
6	CAN-High wire of the high-speed bus CAN Highspeed (ISO 15765-4, SAE-J2284)
7	K-Line (ISO 9141-2, ISO 14230)
8	Not used
14	CAN-Low wire of the high-speed bus CAN Highspeed (ISO 15765-4, SAE-J2284)
15	K-Line (ISO 9141-2, ISO 14230)
16	Battery power supply, +12 / + 24 V

Terminal Connection

Connect the terminal to the connector of vehicle's OBDII.

Setting Overview

To achieve the high accuracy of VH geolocation and the faster search for satellites after turning on the ignition, the location of the OBDII terminals should ensure a good radio coverage of the horizon. If necessary, use an OBD extension cable.

Setting Overview

Omnicom terminals may be configured in three ways:

1. In the Omnicomm Configurator when the terminal is connected to a PC
2. In the Remote Configuration Server (RCS) – remotely
3. By SMS commands

Setting Overview

Default Settings

Setting name	Default value	User manual section
Access point name (APN)	Not specified	GPRS Connection
Phone number	Not specified	GPRS Connection
“Login (APN)” and “Password (APN)”	Not specified	GPRS Connection
CS 1 IP address or domain name	cs.dc2.omnicomm.ru	Connection to Communication Servers
Port	9977	Connection to Communication Servers
Data collection timer	30 sec	Data Collection
Operation mode with ignition off and power on	Collect data at jolting Collection all data is disabled	Data Collection
Data sending interval to CS in roaming	60 min	Data Transmission to a Communication Server
Adaptive data collection at cornering	Enabled	Data Collection
Collecting data on the travelled distance	Enabled	Data Collection
Distance traveled	100 m	Data Collection

Setting Overview

Setting name	Default value	User manual section
Coordinate drift filtering	Disabled	Data Collection
Data sending interval to CS in the home network	2 min	Data Transmission to a Communication Server
GSM and SMS communication parameters	Disabled	Data Transmission to a Communication Server
Roaming parameters	Allowed	Data Transmission to a Communication Server
Data packet size to send to the CS in the home network	300 kB	Data Transmission to a Communication Server
The criterion for the connection of the terminal to the CS	Data packet size to send to the CS	Data Transmission to a Communication Server
Data packet size to send to the CS in roaming	300 kB	Data Transmission to a Communication Server
Data packet size to send to the CS in roaming	300 kB	Data Transmission to a Communication Server
Ignition key status	Voltage Threshold voltage - 13,5 V	Selection of Ignition Source
Vehicle speed	GPS	Selection of Speed Source
Engine RPM	OBD bus	Engine RPM

Setting Overview

Setting name	Default value	User manual section
Fuel level sensors	OBD bus Fuel tank volume - 100 l	Fuel Level Sensors
Parameters of the internal battery	Disabled	Internal Battery
Password setting	Not set	Setting Password on Configuration Changing
Accelerometer	Disabled	Driving Safety Control
Safe driving. Speed	80	Driving Safety Control
Safe driving. Speed. Deviation	5	Driving Safety Control
Safe driving. Speed. Duration	15	Driving Safety Control
Safe driving. RPM	4000	Driving Safety Control
Safe driving. RPM. Deviation	200	Driving Safety Control
Safe driving. RPM. Duration	15	Driving Safety Control
Sound notification	Disabled	Driving Safety Control
Send SMS for selected events	Disabled	Driving Safety Control
Dangerous driving. Acceleration threshold	0,2 g	Driving Safety Control
Dangerous driving. Deceleration threshold	0,2 g	Driving Safety Control

Setting Overview

Setting name	Default value	User manual section
Dangerous driving. Lateral acceleration threshold	0,2 g	Driving Safety Control
Dangerous driving. Vertical acceleration threshold	0,4 g	Driving Safety Control
Accident. Acceleration threshold	4 g	Driving Safety Control
Accident. Deceleration threshold	4 g	Driving Safety Control
Accident. Lateral acceleration threshold	4 g	Driving Safety Control
Accident definition	Disabled	Driving Safety Control
AUTOTILT	Disabled	Driving Safety Control
OBDII parameters	Not selected	OBD Bus

Primary Activation

Activate the OBDII terminal before the usage.

For terminal activation:

- set the owner's phone to the terminal using SMS command *pass tel +yyyyyyyyyyy#

or


- switch on the usage of the internal battery and accelerometer in Omnicomm Configurator

Setting Overview

Switch off the usage of the internal battery and accelerometer before long transportation and storage of the terminal.

Omnicom Configurator

1. Connect the terminal to a PC using a USB cable
2. Install and run Omnicomm Configurator. A window will open:



3. Select equipment – “Terminal”.

List of parameters shown in advanced mode only:

In the “Communication” section:

- Data acquisition and transmission blocking
- Communication Server No. 2 connection settings
- GSM and SMS communication parameters
- Roaming connection parameters
- Roaming parameters

In the “Auxiliary Equipment” section:

Setting Overview

- Accelerometer parameters

In the “OBD” section:


- Service IDs (SIDs) and parameter IDs (PIDs) defined by SAE J1979

The “Driving control” section.

After setting OBDII to ensure IP52 protection, apply the OBDII protective sticker, including in the delivery set.

Remote Configuration Server (RCS)

To connect to the configuration server, open the browser and in its address bar enter the address <http://config.omnicomm.ru>. A window will open:



To add terminals:

1. In the “Terminal ID” field enter the terminal identification number
2. In the “Password” field enter the password set in the terminal during its setting using Omnicomm Configurator
3. Press the “+” button

SMS Commands

Commands Format

All commands sent not from the owner number, must start with a password.

1. The commands must be typed in Latin characters (case-insensitive)

Setting Overview

2. Command parameters must be listed separated by space
3. Only one command must be send in one message
4. All system commands must start with a password
5. Primary terminal setting must start with the owner telephone setup with the use of Omnicomm Configurator or SMS

Command format:

Command head	Password	Command	Command parameters	Command end
*	not-mandatory field	mandatory field	not-mandatory field	#

Command example: *3245 channel sms#

Command head	Password	Command	Command parameters	Command end
*	3245	channel	sms	#

Setting Overview

System Commands

Owner telephone number change

To setup or change the owner telephone number, the password will be required.

Default password: 0000. The response is sent to the number which the command had been sent from.

Command text in SMS	Comments	Example
*pass tel +yyyyyyyyyy#	pass — password +yyyyyyyyyy is the new number (international format, 20 characters maximum)	*1234 tel +79099091122#

Setting Overview

Response to command	Comments
tel changed	telephone number was changed
Potential Errors	Comments
tel. Wrong pass	Wrong password
tel. Wrong number. Start from '+', ≤20digits	invalid number format

Changing Password

Password can be changed only from the owner telephone.

Command text in SMS	Comments	Example
*pass xxxx#	xxxx — new password. Max 8 characters (Latin letters, numbers). Password is case-insensitive. Default value – 0000	*pass 12345#

Response to command	Comments
pass changed	password was changed
Potential Errors	Comments
pass. Wrong owner number	invalid owner number

Setting Overview

Response to command	Comments
pass. Wrong pass. Only digits,↔8digits	invalid password format

Changing Device Name

Command text in SMS	Comments	Example
* **** name NAME DEVICE#	**** – password DEVICE NAME – device name up to 20 characters no spaces (Latin letters, digits, symbols)	*1234 name SuperOBD_22#

Response to command	Comments
name changed	device name was changed
Potential Errors	Comments
name. Wrong pass	Wrong password
name. Wrong name. Only ASCII,↔20 symbols	invalid name format

Setting Overview

Setting Date and Time

Command text in SMS	Comments	Example
* **** time DD-MM-YYYY HH:mm#	DD-MM-YYYY HH:mm – day / month / year / hours / minutes	*1234 time 21-07-2018 12:50#

Response to command	Comments
time changed to DD-MM-YYYY HH:mm	date and time were changed
Potential Errors	Comments
time. Wrong pass	Wrong password
time. Wrong args	invalid date and time format

Enabling/Disabling SMS Notifications

Command text in SMS	Comments	Example
* **** SMS on# * **** SMS off#	on — enabled off — disabled	*1234 SMS on#

Response to command	Comments
SMS on SMS off	on — enabled off — disabled

Setting Overview

Response to command	Comments
Potential Errors	Comments
SMS. Wrong pass	Wrong password
SMS. Wrong args	invalid command format

Configuring Network

Command text in SMS	Comments	Example
* **** net APN login password#	depends on mobile operator login, password are optional	*1234 net internet.mts.ru mts mts#, *1234 net internet.mts.ru#

Response to command	Comments
APN changed to XXX	XXX – set APN
Potential Errors	Comments
net. Wrong pass	Wrong password
net. Wrong args	invalid command format

Setting Overview

Configuring CS

Command text in SMS	Comments	Example
* **** server CS address port protocol#	default values: cs.omnicomm.ru 9977 Omnicommm	*1234 cs.omnicomm.ru 9977 Omnicommm#

Response to command	Comments
server changed to CS address: port, protocol	settings were changed
Potential Errors	Comments
server.Wrong pass	Wrong password
server.Wrong args	invalid command format

Terminal Reboot

Command text in SMS	Comments	Example
* **** restart#	terminal reboot	*1234 restart#

Response to command	Comments
restart OK	terminal was restarted

Setting Overview

Response to command	Comments
Potential Errors	Comments
restart. Wrong pass	Wrong password

Connecting to the Remote Configuration Server

Command text in SMS	Comments	Example
* **** update #	connecting to the RCS	*1234 update#

Response to command	Comments
update started	
Potential Errors	Comments
update. Wrong pass	Wrong password

Resetting to Defaults

Command text in SMS	Comments	Example
* **** default settings #		*1234 default settings#

Setting Overview

Response to command	Comments
reset settings OK	reset to default settings is completed
Potential Errors	Comments
reset settings. Wrong pass	Wrong password

Setting Overview

Settings

Setting the Data Sending Interval

Command text in SMS	Comments	Example
*period XXXX YYYYZ#	XXXX — sending interval for data within the home network, min. Default value: 10. YYYY – sending interval for data in roaming 0 – sending is not performed. Z: min – sending data in roaming (by time), k – sending data in roaming (by package size). Default values: XXXX – 10 min, YYYYmin – 0 min	*period 100 150k#, *period 50 150min#, *period 1000 0#

Setting Overview

Response to command	Comments
period changed to XXXX YYYY min period changed to XXXX YYYY kb period changed to XXXX. Roaming disabled	XXXX – data sending interval in the home network, min; YYYY – data sending interval in roaming, min XXXX – data sending interval in the home network, min; YYYY – data package size to be sent in roaming, kB XXXX – data sending interval in the home network, min; roaming disabled
Potential Errors	Comments
period. Wrong pass	Wrong password
period. Wrong args	invalid command format

Setting the Data Collection Interval

Command text in SMS	Comments	Example
*interval XXXX#	XXXX – data collection, sec 0 – collection/sending blocking (timer value remains unchanged). Possible values: from 15 to 240 sec	*interval 100#

Setting Overview

Response to command	Comments
interval changed to XXX interval. Block enabled	XXX – data collection interval, sec blocking is enabled
Potential Errors	Comments
interval. Wrong pass	Wrong password
interval. Wrong args	invalid command format

Setting Fuel Tank Volume

Command text in SMS	Comments	Example
*volume XXX#	XXX – tank volume, l. Possible options: from 0 to 65000	*volume 100#

Response to command	Comments
volume changed to XXX	XXX – tank volume, l
Potential Errors	Comments
volume. Wrong pass	Wrong password
volume. Wrong args	invalid command format

Setting Overview

Selecting OBD Parameters Sent

The parameter selection command starts with 'obd' and then list parameters, values of which must be sent in SMS.

The current fuel volume is calculated at the terminal based on the data acquired via the OBD bus, and the set tank volume.

Command text in SMS	Comments	Example
*obd speed voltage rpm fuel rate temp key engine#	speed – speed voltage – voltage of the on-board power supply rpm – engine RPM fuel – volume of fuel in the tank (l) rate – fuel consumption rate temp – oil temperature key – ignition engine – error indications Check Engine off – disable sending of all parameters	*obd speed fuel# and *obd off#

Response to command	Comments
obd. speed on, fuel on obd. Disable all	only those parameters are listed, data of which will be sent data Data of all parameters are parameters

Setting Overview

Potential Errors	Comments
obd. Wrong pass	Wrong password

Enabling / Disabling Message Sending when Removing the OBD Terminal

Command text in SMS	Comments	Example
*remove on# *remove off#	on — enabled off — disabled	*remove on#, *remove off#

Response to command	Comments
remove on remove off	on — enabled off — disabled
Potential Errors	Comments
remove. Wrong pass	Wrong password
remove. Wrong args	invalid command format

Setting Overview

Enabling Automatic Message Sending in Case of a Vehicle Position Change

Autotilt — enables tilt mode 2 minutes after ignition off without an SMS sent.

Disables tilt upon ignition on. SMS is sent to the user with a two-minute delay, if the ignition was not on during this time.

The command is sent with the only one parameter.

Command text in SMS	Comments	Example
*autotilt X#	X – sensitivity off – no sending performed on – sending enabled 1 – low 9 – high. If the command is sent without parameters, the mode will be enabled with the present sensitivity. Default value: 5	*autotilt on#

Response to command	Comments
autotilt on X autotilt. SMS on autotilt. SMS off	X – sensitivity off – no sending performed on – sending enabled 1 – low 9 – high

Setting Overview

Enabling Message Sending During Dangerous Driving

Dangerous Driving is the consequence of accelerations and decelerations, as well as in the direction perpendicular to the vehicle movement trajectory, caused by swift lane switches or a sharp movement direction change.

The command is sent with the only one parameter.

Command text in SMS	Comments	Example
*danger on# *danger off# *danger sms on# *danger sms off# *danger acc 5 or acc on or acc off# *danger turn 5 or turn on or turn off# *danger brake 5 or brake on or brake off# *danger vertacc 5 or vertacc on or vertacc off#	activation of dangerous driving control disabling dangerous driving control enabling SMS notifications by preset parameters disabling SMS notifications by preset parameters setting acceleration threshold setting lateral acceleration threshold setting braking threshold setting vertical acceleration threshold threshold values: from 1 (low) to 9 (high)	*danger on#, *danger sms off#, *danger acc 1#, *danger turn 1#, *danger brake 1#, *danger vertacc 1#

Setting Overview

Response to command	Comments
danger on danger. sms on danger. sms off danger. acc on - 5 danger. brake off	dangerous driving control enabled SMS notifications enabled SMS notifications disabled acceleration threshold control enabled and set equal to 5 braking threshold control disabled

Setting Overview

Enabling Message Sending in Case of Emergency

Emergency is a harsh braking or acceleration that may be caused by an accident (crash)

The command is sent with the only one parameter.

Command text in SMS	Comments	Example
*crash on# *crash off# *crash sms on# *crash sms off# *crash acc X# *crash turn X# *crash brake X#	enabling crash control disabling crash control enabling SMS notifications by preset parameters disabling SMS notifications by preset parameters setting acceleration threshold setting lateral acceleration threshold setting braking threshold X – threshold values: from 1 (low) to 9 (high)	*crash on#, *crash sms off#, *crash acc 1#, *crash turn 1#, *crash brake 1#

Setting Overview

Response to command	Comments
crash on crash. sms on crash. sms off crash. acc on - 5 crash. brake off	crash control enabled SMS notifications enabled SMS notifications disabled acceleration threshold control enabled and set equal to 5 braking threshold control disabled

Setting Overview

Parameter Setting Request

Requesting Device Info

Command text in SMS	Comments	Example
*info?#		*info?#

Response to command	Comments
info: SW Dev XXXXXXXX HW Dev YYYYYY time DD-MM-YYYY HH:mm	XXXXXXX – firmware version DD-MM-YYYY HH:mm – device time

Requesting Command Info

Command text in SMS	Comments	Example
*?#	Requesting Command List	*?#

Response to command	Comments
help: info, period, interval, volume, obd, remove, autotilt, danger, crash, balance, dervice, gps	list of commands without parameters

Setting Overview

Requesting Present Data Sending Interval in the Home Network and in Roaming

Command text in SMS	Comments	Example
*period?#		*period?#

Response to command	Comments
period: home XXXXmin roam YYYYmin	XXXX – data sending interval in the home network, min YYYY – data sending interval in roaming, min

Requesting Preset Data Collection Interval

Command text in SMS	Comments	Example
*interval?#		*interval?#

Response to command	Comments
interval: XXXX	XXXX – data collection interval, s

Setting Overview

Requesting Preset Fuel Tank Volume

Command text in SMS	Comments	Example
*volume?#		*volume?#

Response to command	Comments
volume: XXX	XXX – fuel tank volume, l

Setting Overview

Requesting OBD Parameters Sent

Command text in SMS	Comments	Example
*obd?#		*obd?#

Response to command	Comments
obd speed X voltage X rpm X fuel X rate X temp X key X engine X	X – on (enabled) / off (disabled)

Setting Overview

Current Values Request

Requesting Balance

Command text in SMS	Comments	Example
*balance,*100##	*100# – balance request code that depends on operator	*balance,*102##

Response to command	Comments
balance: XXX	XXX – current balance of the active SIM

Mileage After Error Reset, km

Command text in SMS	Comments	Example
*service#		*service#

Response to command	Comments
service: distance XXXX time YYYY	XXXX – mileage after error reset, km

Setting Overview

Requesting Current GPS Parameters

Command text in SMS	Comments	Example
*gps#		*gps#

Response to command	Comments	Example
gps sats X speed YYY point ZZZZ,NNNN	X – number of satellites YYY – speed ZZZZ,NNNN – coordinates in the URL form	GPS: sats - 5, speed - 69, point: http://google.com/maps?q=55.7885,37.5891
Potential Errors	Comments	
GPS. No valid data	GPS data not obtained	

Requesting Current OBD Parameters

Command text in SMS	Comments	Example
*obd#		*obd#

Setting Overview

Response to command	Comments
obd: current values	current values are displayed depending on settings. Fuel volume (% of the fuel tank volume). Volume format depends on the vehicle type

Operation Parameters Setting

Event Notifications

Messages are sent to the owner telephone once the event is logged.


Event	SMS Content	Event Description
remove	remove current date and time GPS coordinates in the URL form	terminal removal
danger	danger current date and time GPS coordinates in the URL form	dangerous driving
crash	crash current date and time GPS coordinates in the URL form	accident (crash)

Operation Parameters Setting

GPRS Connection

In the «**Settings**» tab select the «**Connection**» section from the list.

In the «**GPRS Settings**» section:



«Access Point Name (APN)» – enter the GPRS access point name:

- «VimpelCom» (Beeline) – internet.beeline.ru

Operation Parameters Setting

- «MTS» – internet.mts.ru
- «MegaFon» – internet

For GPRS access point names of other operators, refer to the mobile network operator, whose SIM card is inserted in the terminal.


«Phone number» – number of the SIM card inserted in the terminal.

«Login (APN)» and «Password (APN)» – if necessary, enter login and password for APN access point. Login and password are provided with the SIM card of a number of mobile network operators.

OBD Bus

In the «**Settings**» tab select the «**OBD**» section from the list.

In the «**OBD Parameters**» section:



Default OBDII parameters are not selected.

From the list of parameters, choose the ones you wish to display the value of in Omnicomm Online and check the corresponding boxes.

List of parameters:

- Check Engine Error
- Revolutions, rpm

Operation Parameters Setting

- Speed, km/h
- Fuel volume, %
- Mileage after Maintenance, km
- Coolant temperature, °C
- Voltage, V
- Time to Maintenance, min
- Oil temperature, °C
- Instant fuel consumption, L/h

Value — parameter value obtained from the terminal.

OBD parameters tab to SAE J1979, SAE J1939

Parameter	Protocol			
	SAE J1979		SAE J1939	
	SID	PID	PGN	SPN
Check Engine Error	0*01	0x01	FECA	1213
Revolutions, rpm	0*01	0x0C	F004	190
Speed, km/h	0*01	0x0D	FEF1	84
Fuel volume, %	0*01	0x2F	FEFC	96
Mileage after Maintenance, km	0*01	0x31	-	-
Coolant temperature, °C	0*01	0x05	FEFE	110
Voltage, V	0*01	0x42	FEF7	168

Operation Parameters Setting

Parameter	Protocol			
	SAE J1979		SAE J1939	
	SID	PID	PGN	SPN
Time to Maintenance, min	0*01	0x4E	-	-
Oil temperature, °C	0*01	0x5C	FEFE	175
Instant fuel consumption, L/h	0*01	0x5E	FEF2	183

SID – Channel ID by SAE J1979.

PID – Parameter ID to SAE J1979.

PGN – No. of parameters group, defining the contents of the corresponding message according to SAE J1939.

SPN – code of the parameter according to SAE J1939.

Connection to Communication Servers

In the «**Settings of connection to the communication server**» sections:

«CS 1 IP address or domain name» – enter IP address or domain name of the communication server: cs.dc1.omnicomm.ru.

«Port» – enter port to be used by terminal to connect to the communication server: 9977


Operation Parameters Setting

«Protocol» – select data transmission protocol to the CS. Possible options: Omnicomm.

Data Collection

In the «**Settings**» tab select the «**Connection**» section from the list.

In the «**Data collection parameters**» section:



«Data collection timer» – set the value of the period of Terminal requesting modules and external devices connected to it. Value range: from 15 to 240 s. Default value — 30 s.

«Operation mode with ignition off and power on» select:

- «Collect all data» – data collection and transmission same as with ignition turned on
- «Collect all except GPS» – collection and transmission of data selected during configuration of the terminal, except for the GPS module data
- «Collect data at jolting» – monitoring the status of the accelerometer. If the accelerometer reading changes by more than 0.2 g, the terminal switches to the “Collect all data” and performs data transmission to the Communication Server in 5 minutes

Selecting «Collect data at jolting» set the following configuration:

- «Collect all data» – when this parameter is enabled, the terminal upon expiration of the time specified in the “Interval of sending data to the server” switches to the “Collect all data” mode and performs data collection and transmission to the communication server. After the data transmission the terminal switches to the “Collect data at jolting” mode.
- «Interval of sending data to the server» – the time interval between the terminal connections to CS. Possible values: 1 to 6 hours, at intervals of 1 hour.

Operation Parameters Setting

Depending on the set mode, the data are collected from the particular modules and external devices. Default value: "Collect data at jolting".

«Adaptive data collection at cornering» – enable/disable adaptive data collection at cornering, which allows increasing the accuracy of displaying turns on the map by additional data collection from the GPS module more frequently than set in the "Data collection timer" parameter. Default value — enabled.

«Collecting data on the travelled distance» – allows increasing the accuracy of displaying the vehicle location on the map by additional data collection from the GPS module over the distance traveled between the events with registered coordinates. Default value — enabled.

«Distance traveled» – enter the mileage traveled from the moment of the last registered event with coordinates, upon achieving which the data will be collected. Possible values: 10 to 1000 meters. Default value – 100 meters. Default value — disabled.

«Coordinate drift filtering» – enable to eliminate drift of coordinates during the "Track" report generation.

When enabling the "Coordinate drift filtering" the following settings are available:

- "Delay after ignition on, s". Default value – 35 s. Possible values: 0 to 900.
- "Maximum travel speed, km/h". Default value - 180 km/h. Possible values: 5 to 360.

The default values allow elimination of drifts for most cases and do not require correction.

Data Transmission to a Communication Server

In the «**Settings**» tab select the «**Connection**» section from the list.

In the «**Parameters of output for connection**» section:



«Data submission period to CS» – enter the number of minutes, upon expiration of which the Terminal must establish connection with the communication server, while being in the mobile operator's home network. Recommended value – 10 min. Default value – 2 minutes.

In the «**GSM and SMS communication parameters**» section:

Operation Parameters Setting

GSM and SMS parameters

SMS: On

SMS number:

SMS template language: English

Vehicle name:

GSM and SMS communication parameters

☒ Headset: Off

☒ SMS: On

☒ Number for sending SMS:

☒ SMS template language: Russian

☒ VH name:

«SMS» – enable/disable the commands reception via SMS and sending the information messages by the Terminal. Default value — disabled. When the “SMS” parameter is enabled:

«SMS destination number» – enter the phone number, to which the SMS will be sent with information about the status of the Terminal and the vehicle.

«SMS template language» – select the language of the SMS template. Possible options: Russian, English, Portuguese, Spanish.

«Vehicle Name» – enter the name of the vehicle. The “Vehicle Name” field is mandatory.

In the **«Roaming connection parameters»** section:

Roaming connection parameters

Connection parameters: By period

Interval of sending data to CS (min): 60

Connection establishing in roaming parameters

☐ Connection establishing upon event: Sending period

☐ Period of data transfer to CS (min): 60

Select the criterion for the connection of the terminal to the CS: “By time period” or “By packet size”. Default value — “Interval of sending data to the CS”.

«Interval of sending data to the server» – enter the number of minutes, upon expiration of which the terminal must establish connection with the communication server, while being in roaming. Recommended value – 180 minutes. Default value – 60 min.

«Data packet size to send to the CS» – enter the data packet size, upon achieving which the terminal must establish connection with the communication server, while being in roaming. Recommended value – 100 Kb.

In the **«Roaming parameters»** section:

Roaming parameters

Roaming configuration for: SIM1

Roaming: By list

MCC: MNC:

Add Up Down Delete

NP: MCC + MNC:

Roaming parameters

☒ Roaming for SIM1: Prohibited

«Roaming» – select the option of SIM card using while in roaming. Default value — allow. Possible options:

Operation Parameters Setting


- «Permitted» – the terminal will transmit data using the available cellular networks
- «Prohibited» – the terminal will not transmit data while roaming
- «In roaming as at home network» – the terminal will transmit data following the same settings of output parameters as for the home network
- «According to the list» – the terminal will only transmit data using the cellular networks stated in the list. Enter the MCC and MNC of the required cellular networks in the table

When the terminal operates in roaming, the data transmission is carried out only to the communication server no. 1. To transfer data to two communication servers, select "In roaming as at home".

Selection of Ignition Source

In the «**Settings**» tab select the «**Inputs**» section from the list.


In the «**Ignition key status**» section:



Ignition key status

Data source: Voltage

Threshold voltage, V: 13.5



Ignition key status

Data source: On-board voltage

☐ Ignition on threshold for on-board voltage change: 8.1

«Data source» – select the data to register ignition on/off.


«Onboard voltage» – the ignition on is registered upon reaching the vehicle network power supply threshold voltage.

«Threshold voltage» value: when this value is reached, the ignition will register as switched on. Ignition off is registered, when the voltage drops to 0,5 V below the threshold. Default value – 13,5 V.

Selection of Speed Source


In the «**Settings**» tab select the «**Inputs**» section from the list.

In the «**Vehicle speed**» section:



Vehicle speed

Data source: GPS



Speed input parameters

☒ Operation mode: GPS


«Data source» – select the data to process the speed values. Possible options: "GPS", "OBD bus".

Operation Parameters Setting

Engine RPM

In the «**Settings**» tab select the «**Inputs**» section from the list.

In the «**Engine RPM**» section:




The image shows two parts of the settings interface. On the left is a dark-themed panel titled 'Engine RPM' with a 'Data source' dropdown menu currently set to 'Off'. On the right is a light-themed panel titled 'RPM input parameters' which has a checked 'Signal type' checkbox and a dropdown menu set to 'RPM input'.

«Data source» – select the signal type. Possible values: “Disabled”, “OBD bus”

Fuel Level Sensors

In the «**Settings**» tab select the «**Inputs**» section from the list.

In the «**Fuel Level Sensors**» section:



The image shows two parts of the settings interface. On the left is a dark-themed panel titled 'Fuel level sensors' with a 'Data source' dropdown set to 'OBD bus', a 'Fuel tank volume, L' input field with '100', and a 'Current fuel volume, L' display showing '0.00'. On the right is a light-themed panel titled 'Fuel sensor parameters' with an unchecked 'Sensor types' checkbox and a dropdown menu set to 'Digital LLS'.

«Data source» – select the signal type. Possible values: “Disabled”, “OBD bus”. Default value — OBD bus.


«Fuel tank volume, L» – enter the fuel tank volume. Default value — 100 L.

«Current fuel volume, L» – displays the current volume of fuel in the tank. The current fuel volume is calculated at the terminal based on the data acquired via the OBD bus, and the set tank volume.

Internal Battery

In the «**Settings**» tab select the «**Auxiliary equipment**» section from the list.

In the «**Internal battery parameters**» section:




The image shows a dark-themed panel titled 'Internal battery parameters' with a 'Use internal battery' dropdown menu currently set to 'On'.

«Use internal battery» – enable/disable use of internal battery when the main power supply is turned off and the terminal is operating in the “Collect data during pounding” mode.

Driving Safety Control

In the «**Settings**» tab select the «**Auxiliary equipment**» section from the list.

In the «**Accelerometer parameters**» section:



▼ Accelerometer parameters

Accelerometer On

Accelerometer status Not used

Accelerometer calibration Auto

Clear results

“Accelerometer” – enable/disable the use of accelerometer for measuring the vehicle acceleration. Default value — enabled.

“Accelerometer status” – accelerometer condition. Possible options: not used, calibration, calibrated, calibration error.


“Accelerometer calibration” – select the accelerometer calibration mode. Possible options: automatic calibration, manual calibration.

Prior to performing the calibration, firmly fix the terminal and do not change its position during operation.

Automatic calibration is recommended for vehicles that are operated mainly at speeds above 50 km/h. Automatic calibration takes between 2 minutes and 24 hours, depending on the frequency of acceleration and braking on straight sections of the road.

When selecting manual calibration, in the “Terminal position” field, select one of 24 positions as shown in figure:

Operation Parameters Setting



Deflection of the terminal from the axes during manual calibration should not be more than 5 degrees.

In the «**Settings**» tab select the «**Driving Control**» section from the list.

«**Dangerous driving control**» – enable/disable registration of dangerous driving when exceeding the set values of monitored parameters.

Operation Parameters Setting

	Event sending	Threshold	Error	Duration, s	Sound notification
Speed, km/h	<input checked="" type="checkbox"/>	80	5	15	<input type="checkbox"/>
Revolutions (rpm)	<input checked="" type="checkbox"/>	4000	200	15	<input type="checkbox"/>
Acceleration, g	<input checked="" type="checkbox"/>	0.20			<input type="checkbox"/>
Lateral acceleration, g	<input checked="" type="checkbox"/>	0.20			<input type="checkbox"/>
Braking, g	<input checked="" type="checkbox"/>	0.20			<input type="checkbox"/>
Vertical acceleration (pounding/impact), g	<input checked="" type="checkbox"/>	1.00			<input type="checkbox"/>

☐ Send SMS for selected events

Select monitored parameters:

«**Sending an event**» –enable/disable event sending to Omnicomm Online.

- «Speed» – vehicle speed control

Threshold – enter the maximum permissible speed, upon exceeding which dangerous driving will be registered. Possible values: 0 to 150 km/h. Default value: 80 km/h.

Deviation – enter the speed value that can be exceeded maximum permissible speed without triggering dangerous driving. Possible values: 0 to 50 km/h. Default value: 5 km/h.

Duration – enter the period of time allowed to exceed maximum permissible speed without triggering dangerous driving. Possible values: 0 to 300 s. Default value: 15 s.

- «Engine speed (RPM)» – engine RPM monitoring

Threshold – enter the maximum permissible engine RPM, upon exceeding which dangerous driving will be registered. Possible values: 0 to 10,000 rpm. Default value: 4,000 rpm.

Deviation – enter the RPM value that can be exceeded by maximum permissible RPM without registration of violation. Possible values: 0 to 1000 rpm. Default value: 200 rpm.

Duration – enter the period of time allowed to exceed maximum permissible engine RPM without registration of dangerous driving. Possible values: 0 to 300 s. Default value: 15 s.

- «Acceleration» – acceleration control during vehicle speeding up

Threshold – enter the value of acceleration while speeding up, which exceeding will trigger registration of dangerous driving

Service Functions

- «Lateral acceleration» – acceleration control during vehicle turning

Threshold – enter the value of acceleration while turning, which exceeding will trigger registration of dangerous driving

- «Braking» – acceleration control during vehicle braking


Threshold – enter the value of acceleration while braking, which exceeding will trigger registration of dangerous driving

- «Vertical acceleration (pounding / bumping)» – acceleration control during vehicle pounding

Threshold – enter the value of acceleration while pounding or bumping, which exceeding will trigger registration of dangerous driving

- “Send SMS for selected events” – enable SMS sending upon registration of dangerous driving

«**Determine accidents**» – enable / disable accident registration upon exceeding the set values of monitored parameters.



▼ ☒ Accident control ●

Acceleration threshold, g 2.00

Lateral acceleration threshold, g 2.00

Braking threshold, g 2.00

● ☒ Send SMS on triggering

- «Speeding up threshold» – value of acceleration while speeding up, which exceeding will trigger registration of accident
- «Lateral acceleration threshold» – value of acceleration while turning, which exceeding will trigger registration of accident
- «Braking threshold» – value of acceleration while braking, which exceeding will trigger registration of accident
- «Send SMS upon triggering» – enable SMS sending upon registration of accident

Service Functions


Terminal Reboot

In the "Service" menu select "Restart Terminal".

Setting Password on Configuration Changing


In the «**Settings**» tab select the «**Auxiliary equipment**» section from the list.

In the «**Password settings**» section:



The left screenshot shows the 'Password settings' section with a dropdown menu set to 'Off' and a 'Change password' button. The right screenshot shows the 'Password management' section with checkboxes for 'Password' and 'Request password while saving', both checked, and input fields for the password and request frequency.

If you need to use a password to configure the terminal settings, in the field "Ask for password when saving settings" select "Enabled". Default value — disabled. Press the "Record into device" button. A window will open:




The dialog box is titled "Password change". It contains a checkbox labeled "Show password". Below the checkbox are two input fields: "New password" and "Confirm new password". At the bottom right are two buttons: "CANCEL" and "SAVE".

"New password" and "Confirm new password" – enter a new password that will be used to get access to settings configuration. The password shall contain 8 characters maximum.

Press the "Save" button. A window will open:

Service Functions



Press the “Save” button.



Press the “Record into device” button.

Data Collection and Transmission Blocking

In the «**Settings**» tab select the «**Connection**» section from the list.

In the «**Data collection and transmission blocking**» section:

To block the terminal data collection and transmission in the “Lock” field select “Enabled”:



To unlock data collection and transmission use Omnicomm Configurator or send SMS command *UNBLOCK# to the SIM card, inserted in the terminal.

Remote Configuration Server Operation Setting

Set password on terminal settings modification by either of the following ways:

- When configuring the terminal using Omnicomm Configurator set password on settings modification that is different from the password set by default. Default password – 0000
- Send SMS command to change password set by default: *SETPWDID 212009988 12345#

where: 212009988 – terminal ID; 12345 – password to be set. The password shall contain 8 characters maximum and may include any digits and letters.

The previously set password cannot be changed in this way.

After 6 hours, the terminal will be authorized on the Remote Configuration Server and will be available for operation via the Remote Configuration Server.

Terminal SIM Card Number Identification


The terminal SIM card telephone number is automatically displayed in the Remote Configuration Server after the second connection to the RCS.

SMS sending shall be enabled for the SIM card.

Installation of a Protective Sticker

Installation of a Protective Sticker

After installation of the SIM card and setting up the terminal, apply the OBDII protective sticker according to the picture:



Sealing

Stick the sealing sticker on the connector so that the terminal cannot be switched off without breaking the sticker.

Specifications

	Omnicommm OBDII
Communication	
Satellite Navigation Systems	GLONASS/GPS
Data transmission channel	GPRS
Number of SIM cards and SIM chips	1 SIM card
SIM chip available	No

Installation of a Protective Sticker

	Omnicom OBDII
Communication	
Power source	
Power supply voltage, V	8...30
Overvoltage protection	Yes
Data collection and transmission	
Data collection period, s	15...240
Non-volatile memory capacity, events	150 000
Interfaces	
CAN interfaces	Protocols ISO 15765-4, SAE-J2284, J1939, J1979
USB interfaces	Yes
Built-in accelerometer	Yes
Design	
Dimensions, mm	50,8 x 46,5 x 23,5
Degree of enclosure protection	IP52 (only when using a protective sticker)
Operating temperature range, C	– 40...+85
Capabilities	

Installation of a Protective Sticker

	Omnicom OBDII
Communication	
Remote control through GPRS	Yes
SMS notifications	Yes

OMNICOMM

info@omnicomm-world.com

www.omnicomm-world.com